



Active Pickup and System Wiring Diagram



Pickup Color Codes



For All pickup types
the bare wire goes to
ground...Always